

USER GUIDE

IVGM4648/5048

Hybrid solar inverter



Contents

1. SAFETY & WARNING	2
2. Product Introduction	2
2.1 Operation Modes	3
2.2 Products overview	4
3. INSTALLATION	5
3.1 Packing List	5
3.2 Installation tools	6
3.3 Installation Environment	6
3.4 Mounting	8
4. ELECTRICAL CONNECTION	9
4.1 PV Connection	9
4.2 Battery Connection	11
4.3 On-Grid & Back-Up Connection	12
4.4 Smart Meter & CT Connection	16
4.5 Dry Contact Signal	16
4.6 DRMS Connection	15
4.7 Lithium Battery Communication	18
4.8 Installation of WiFi module	19
4.9 Wiring System	20
5. Display and operation	21
5.1 Operation and Display Panel	21
5.2 LCD Display Icons	22
5.3 Base information Page	23
6. Warning Code Table	25
7. Troubleshooting	25
8. Appendix	28

About This Manual

The manual mainly describes the product information, guidelines for installation, operation and maintenance. The manual cannot include complete information about the photovoltaic (PV) system.

How to Use This Manual

Read the manual and other related documents before performing any operation on the inverter. Documents must be stored carefully and be available at all times. Contents may be periodically updated or revised due to product development. The information in this manual is subject to change without notice. The latest manual can be acquired via our website at <http://www.felicitysolar.com> for latest version.









Safety Introductions

This chapter contains important safety and operating instructions. Read and keep this manual for future reference.

- Before using the inverter, please read the instructions and warning signs of the battery and corresponding sections in the instruction manual.
- Do not disassemble the inverter. If you need maintenance or repair, take it to a professional service center.
- Improper reassembly may result in electric shock or fire.
- To reduce risk of electric shock, disconnect all wires before attempting any maintenance or cleaning. Turning off the unit will not reduce this risk.
- Caution: Only qualified personnel can install this device with battery.
- Never charge a frozen battery.
- For optimum operation of this inverter, please follow required specification to select appropriate cable size. It is very important to correctly operate this inverter.
- Be very cautious when working with metal tools on or around batteries. Dropping a tool may cause a spark or short circuit in batteries or other electrical parts, even cause an explosion.
- Please strictly follow installation procedure when you want to disconnect AC or DC terminals. Please refer to "Installation" section of this manual for the details.
- Grounding instructions – this inverter should be connected to a permanent grounded wiring system. Be sure to comply with local requirements and regulation to install this inverter.
- Never cause AC output and DC input short circuited. Do not connect to the mains when DC input short circuits.

1. SAFETY & WARNING

This manual provides relevant information with icons to highlight the physical and property safety of the user to avoid device damage and physical injury. The Symbols used in this manual are listed as below:

Symbols	Name	Instruction
	Danger	Serious physical injury or even death may occur if not follow the relative requirements.
	Warning	Physical injury or damage to the devices may occur if not follow the relative requirements.
	Electrostatic sensitive	Damage may occur if not follow the relative requirements.
	Hot surface	Sides of the device may become hot. Do not touch.
	Earth terminal	The inverter must be reliably grounded.
	Caution	Ensure that DC and AC side circuit breakers have been disconnected and wait at least 5 minutes before wiring and checking.
NOTE	Note	The procedures taken for ensuring proper operation.
	CE mark	The inverter complies with the CE directive.
	EU WEEE mark	Product should not be disposed as household waste.

2. Product Introduction

Felicity Solar TVGM4648/5048 is a multifunctional inverter, combining functions of inverter, solar charger and battery charger to offer uninterrupted power support with portable size. Its comprehensive LCD display offers user configurable and easy accessible button operation such as battery charging, AC/solar charging, and acceptable input voltage based on different applications.




Figure 2.1-1 Block diagram of hybrid solar inverter system

2.1 Operation Modes

IVGM system normally has the following operation modes based on your configuration and layout conditions:

Mode 1: The energy produced by the PV system is used to optimize self-consumption. The excess energy is used to recharge the batteries; the rest is exported to grid.



Mode 2: When there is no PV, and the battery is sufficient, it can supply the load together with grid power.



Mode 3: When grid fails, the system automatically switches to Back-Up mode. The Back-Up load can be supported by PV and battery.



Mode 4: There is no PV, the battery is low, and the battery is charged through the grid.



2.2 Products overview




Figure 2.2-1 Products overview

- | | | |
|-----------------------------|----------------------------|----------------------|
| 1. Inverter Indicators | 6. DC switch | 10. BMS port |
| 2. LCD display | 7. WIFI Communication port | 11. COM port |
| 3. Button | 8. DRMS port | 12. Back-up terminal |
| 4. Battery connection port | 9. PARA port | 13. On-grid terminal |
| 5. PV input connection port | | |




Figure 2.2-2 Inverter dimensions




Figure 2.2-3 Paper packages dimension

Table 2-4 Packages dimension and gross weight

Model	H (mm)	W (mm)	D (mm)	Net Weight (KG)	Gross Weight (KG)
IVGM4648/5048	632	585	315	34.8	40.0

3 Installation

3.1 Packing List

The inverter 100% strictly inspected before package and delivery. Please check the product package and fittings carefully before installation.




Figure 3.1-1 Packing List

Table 3.1-1 Detailed delivery list

No.	Name	Quantity
1.	Inverter	1
2.	Battery connector	1 pair
3.	Operation manual	1
4.	DC connector	2 pairs
5.	WiFi module	1
6.	COM connector	1
7.	Meter+CT (optional)	1
8.	Expansion Bolts	2

3.2 Installation tools



Figure 3.2-1 Installation tools

3.3 Installation Environment

- ◇ Choose a dry, clean, and tidy place, convenient for installation.
- ◇ Ambient temperature range: $-25^{\circ}\text{C} \sim 60^{\circ}\text{C}$
- ◇ Relative humidity: $0 \sim 100\%$ (non-condensed)
- ◇ Install in a well-ventilated place
- ◇ No flammable or explosive materials close to inverter.
- ◇ The AC overvoltage category of inverter is category III.
- ◇ Maximum altitude: 2000m



•Inverter cannot be installed near flammable, explosive or strong electro-magnetic equipment.




Figure 3.3-1 Installation space of one inverter

Ensure there is sufficient space for heat-releasing. Generally, space requirement should be met as below:

Table 3-3-1 Detailed installation space

	Minimum clearance
Lateral	200mm
Top	450mm
Bottom	450mm




Figure 3.3-2 Installation position



•Do not open the cover of the inverter or replace any part as incomplete inverter may cause electric shock and damage the device during operation.

The installation of inverter should be protected under shelter from direct sunlight or badweather like snow, rain, lightning, etc.




Figure 3.3-3 Installation position

3.4 Mounting



•The inverter is heavy, please be careful when removing it from the package.

The inverter is suitable for mounting on concrete or other non-combustible surface only.

Step 1: Please use the mounting bracket as a template to drill 5 holes in the right positions (10mm in diameter, and 80mm in depth). Use M8 expansion bolts in accessory box and fix the mounting. With a 12mm drill bracket onto the wall tightly. The installation of inverter support is shown in Figure 3.4-1.




Figure 3.4-1 Install the inverter hanging plate

Step 2: Lift the inverter to fix it on the installation bracket. We can prevent theft by locking. See Figure 3.4-2.

NOTE

•Be careful when mounting because the inverter is very heavy.




Figure 3.4-2 Installing an Inverter




Figure 3.4-3 Rack earth(Ground wire locked by M5)

4 Electrical Connection

- ⚠ High voltages in power conversion circuits. Lethal hazard of electric shock or serious burns.
- ⚠ All work on the PV modules, inverters, and battery systems must be carried out by qualified personnel only.
- ⚠ Wear rubber gloves and protective clothing (protective glasses and boots) when working on high voltage/high current systems such as INVERTER and battery systems.

4.1 PV Connection

Before connecting PV panels/strings, please make sure requirements are followed as below:

- (1) The total short-circuit current of PV string must not exceed inverter's max DC current.
- (2) The minimum isolation resistance to ground of the PV string must exceed 19.33KΩ in case of any shock hazard.
- (3) PV string could not connect to earth/grounding conductor.
- (4) Use the right PV plugs in the accessory box.

Wire Size	Cable(mm)
12AWG	7

Step 1. Prepare PV positive and negative power cables




Figure 4.1-1 pv cables and pv plugs

Step 2. Connect PV cables to PV connectors. See Figure 4.1-2:



Figure 4.1-2 PV cables to PV connectors

NOTE

- PV cables must be tightly crimped into the connectors.
- For Amphenol connector, the limit buckle cannot be pressed.
- There will be a "click" sound if connectors are inserted correctly into PV plugs.

Step 3. Screw the cap on and plug it onto inverter side. There will be a click sound if connectors are inserted correctly into PV plugs. See Figure 4.1-3.




Figure 4.1-3 The PV plug is connected to the inverter



- The polarity of PV strings cannot be connected reversely, otherwise the inverter could be damaged.

4.2 Battery Connection

Please be careful about any electric shock or chemical hazard. Make sure there is an external DC breaker (125A) connected to the battery without build-in DC breaker.



- The polarity of battery cannot be connected reversely, otherwise the inverter could be damaged.

Wire Size	Cable(mm)
1/0AWG	25

Step 1. Prepare battery cables and accessories, and route the battery power cable through the battery cover. Use accessories box accessories, battery power cable 20-35mm².




Figure 4.2-1 Battery cable and battery case.

Step 2. Make battery terminals. Strip cable coat, revealing 10mm length of metal core. Use special crimper to compress battery terminal tightly.



Figure 4.2-2 The battery terminal

Step 3. Connect the battery terminal to the inverter. Ensure that the battery polarity is connected correctly.




Figure 4.2-3 The battery terminal is connected to the inverter.

4.3 On-Grid & Back-Up Connection

An external AC breaker is needed for on-grid connection to isolate from grid when necessary. The requirements of on-grid AC breaker are shown as below.




Figure 4.3-1 Install AC cables for the inverter



• Don't connect the PE wire wrong.

Table 4.3-1 : Recommended table of AC circuit breakers:

INVERTER MODEL	AC BREAKER SPECIFICATION
IVGM4848/5048	40A/230V,2P

NOTE

• The absence of AC breaker on back-up side will lead to inverter damage if an electrical short circuit happens on back-up side.

1. On the AC side, the individual breaker should be connected between inverter and Grid but before loads. See Figure 4.3-2.




Figure 4.3-2 Ac breaker connection



• Make sure the inverter is totally isolated from any DC or AC power before connecting AC cable.

Step 1. Prepare the terminals and AC cables as below. See Figure 4.3-3.



Figure 4.3-3 Ac connection line

Table 4.3-2: Ac cable specifications

Grade	Description	Value
A	Outside diameter	13-16 mm
B	Separated wire length	20-25 mm
C	Conductor wire length	7-9 mm
D	Conductor core section	4-6 mm ²

Step 2. Using the terminals in the accessory box, pass the AC cable through the terminal cover. See Figure 4.3-4.




Figure 4.3-4 The AC cable passes through the terminal cover

Step 3. Install the AC connection terminal on the cable. See Figure 4.3-5.



Figure 4.3-5 Install ac connection terminals

NOTE

The absence of AC breaker on back-up side will lead to inverter damage if an electrical short circuit happens on back-up side.

Step 4. Connect the combined AC cable to the AC terminal of the inverter, tighten the cable to a torque of 2.0 N.m to 2.5 N.m, and then lock the AC cover. See Figure 4.3-6.




Figure 4.3-6 Install ac connection terminals

4.4 Smart Meter & CT Connection





Figure 4.4-1 Smart Meter

Table 4.4-1: Smart Meter LED Indications

STATUS	OFF	ON	Blinking
Run (Green)	The instrument is not running	/	The instrument is running normally
Com (Red)	The instrument is not communicating	/	The instrument is in communication status
R/P (Red)	Positive power	Negative power	/
- (Red)	/	Negative value indicator lamp	/

Connection Mode

The connection diagram on the instrument housing shall prevail in case of any discrepancies with it.



It is recommended to use 0.5A or 3A for the fuse in the connection diagram.



Make sure the inverter is totally isolated from any DC or AC power before connecting AC cable.



Figure 4.4-2 RS485 interface

Table 4.4-2: RS485 interface

NO.	1	2	3	4	5	6	7	8
Function	485A	485B	485A	GND1	GND1	485B	NC	NC

The Smart Meter with CT in product box is compulsory for IVGM system installation, used to detect grid voltage and current direction and magnitude, further to instruct the operation condition of IVGM inverter via RS485 communication. See Table 4.4-3.

Table 4.4-3 :Detailed Pin Function OF COM Port On IVGM

Position	Function	Note
1	485_A2	RS485-2 For Meter
2	485_B2	
3	485_A3	RS485-3 For Remote Monitor
4	485_B3	
5	485_A3	
6	485_B3	
7	RY_4	Dry Signal
8	RY_5	



Make sure Meter & CT are connected between house loads and grid, and follow the Smart Meter direction sign on CT, refer to Figure 4.4-3.




Figure 4.4-3 Smart meter connection

4.5 Dry Contact Signal

There is one dry contact (3A/250VAC) available on the inverter.

Unit Status	Condition	Dry contact port.
Power-Off	Unit is off and no output is powered.	Open
Power-On	Battery voltage < Setting value in Program 12	Close
	Battery voltage > Setting value in Program 13 or battery charging reaches floating stage.	Open

4.6 DRMS Connection

DRMS(Demand response enabling device) is used for Australia and New Zealand installation (also used as remote shutdown function in European countries), in compliance with Australia and New Zealand safety requirements(or European countries). Inverter integrates control logic and provides an interface for DRMS. The DRMS is not provided by inverter manufacturer. Detailed connection of DRMS & Remote Shutdown are shown below:

Step 1. Screw this plate off from the inverter. See Figure 4.6-1.




Figure 4.6-1 DRMS interface

Step 2. Plug out the RJ45 terminal and dismantle the resistor on it. Plug the resistor out, leave the RJ45 terminal for next step.




Figure 4.6-2 operating steps

NOTE

The RJ45 terminal in the inverter has the same function as DRED. Please leave it in the inverter if no external device is connected.

Step 3-1 Pass the RJ45 cable through the steel plate and connect the DRED cable to the RJ45 terminal. As shown in Figure 4.6-3, Table 4-9 describes the 6-pin port definition.




Figure 4.6-3 operating steps

Table 4.6-1 :Port pin-allocation table

NO.	1	2	3	4	5	6
Function	DRM1/5	DRM2/6	DRM3/7	DRM4/8	REFGEN	COM/DRMO

Step 3-2 For Remote Shutdown, Run the cable through the steel plate. Then wire from pins 5 and 6. Table 4.6-1 describes the 6-pin port definition, Wiring is shown in Figure 4.6-4.



Figure 4.6-4 Remotely close the cable connection

Step 4. Connect RJ45 terminal to the right position onto the inverter. See Figure 4.6-5:





Figure 4.6-5 RJ45 interface

4.7 Lithium Battery Communication

It's allowed to connect lithium battery and build communication only which it has been configured. Please follow bellow steps to configure communication between lithium battery and inverter.

1. Connect power cables between lithium battery and inverter. Please pay attention to the terminals of positive and negative. Make sure the positive terminal of battery is connected to the positive terminal of inverter, and the negative terminal of battery is connected to the negative terminal of inverter.
2. The communication cable is bundled with lithium battery. Both sides are RJ45 port. One port is connected to the BMS port of inverter and another one is connected to the COMM port of lithium battery.



Position	Color	Function
1	Orange&white	/
2	Orange	/
3	Green&white	+VCC
4	Blue	COM-GND
5	Blue&white	RS485-B1
6	Green	RS485-A1
7	Brown&white	CANL1
8	Brown	CANH1

3. Configure battery type to lithium battery on the app



And then LCD will show you "Li" icon.



4. Power up lithium battery and inverter. Wait a moment, if the communication is built between them, LCD will show you "BMS" icon as below.



5. Roll LCD real time information pages by pressing "UP" or "DOWN" button, as below page, you can see the parameters of SOC, battery pack units and other informations in the communication system. LCD will be rolled these parameters or informations automatically.



Battery SOC is 100%

Battery pack units are 2

When it displays :

"b50" means BMS doesn't allow inverter to charge battery

"b51" means BMS doesn't allow inverter to discharge battery

"b52" means BMS require inverter to charge battery

4.8 Installation of WIFI module

The WIFI communication function applies only to the WIFI module. For details, see Figure 4.8-1 installing a WIFI module.




Figure 4.8-1 WiFi Module Installation

4.9 Wiring System




Figure 4.9-1 Inverter wiring system

5. Display and operation


This chapter describes the panel displaying and how to operate on the panel, which involves the LCD display, LED indicators and operation panel.

5.1 Operation and Display Panel





Function Key	Icon	Description
ESC		Hold on the "ESC" button last for 3S to turn off the inverter.
UP		To go to previous selection.
DOWN		To go to next selection.
ENTER		Hold on the "ENTER" button last for 3S to turn on the inverter.
LED Indicator	Icon	Description
Battery		Charging the battery, the LED light flash. If battery is full, the LED light will always on. The battery is not charged, the LED light will go out.
Utility		Inverter running in utility mode, the LED will always on. Inverter is not running in utility mode, the LED will go out.
Inverter		Inverter running in off-grid mode, the LED light will always on. Inverter is not running in off-grid mode, the LED light will go out.
Fault		If inverter in fault event, the LED light will always on. If inverter in warning event, the LED light will flash. Inverter work normally, the LED light will go out.
Buzzer Information		
Buzzer beep		Turn on/off the inverter, the buzzer will last for 2.5s. Press any button, the buzzer will last for 0.1s. Hold on the "ENTER" button, the buzzer will last for 3s. If in fault event, the buzzer will keep going. If in warning event, the buzzer will beep discontinuous (Check more information on the chapter of "Warning Code Table").

5.2 LCD Display Icons

















Icon	Function description
Input Source Information	
	Indicate input voltage, input frequency, PV voltage, PV power, battery voltage and charger current.
Configuration Program and Fault Information	
	Indicates the warning and fault codes. Warning: flashing with warning code. Fault: lighting with fault code.
Output Information	
	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.
Battery Information	
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100%.
	Indicates Lithium battery type.
	Indicates communication is built between inverter and battery.
Mode Operation Information	
	Indicates the utility.
	Indicates load level by 1-25%, 26-50%, 51-75% and 76-100%.
	Indicates the PV panels.

	Indicates PV MPPT is working.
METER	Indicates communication is built between inverter and meter.
Mute Operation	
	Indicates unit alarm is disabled.


5.3 Base information Page

The base information will be switched by pressing "UP" or "DOWN" key. The selectable information is switched as below order:

<p>Input voltage / Output voltage Utility voltage is 230V, output voltage is 230V</p> 	<p>Input frequency / Output voltage Utility frequency is 50.0Hz, output voltage is 230V</p> 
<p>PV1 voltage / Output voltage PV1 voltage is 450V, output voltage is 230V</p> 	<p>PV1 power / Output voltage PV1 power is 3.00kW, output voltage is 230V</p> 
<p>PV2 voltage / Output voltage PV2 voltage is 450V, output voltage is 230V</p> 	<p>PV2 power / Output voltage PV2 power is 3.00kW, output voltage is 230V</p> 

<p>Battery voltage / Output voltage Battery voltage is 50.0V, output voltage is 230V</p> 	<p>Charging current / Output voltage Charging current is 10A, output voltage is 230V</p> 
<p>Battery voltage / Output frequency Battery voltage is 50.0V, output frequency is 50.0Hz</p> 	<p>Battery voltage / Load percentage Battery voltage is 50.0V, load percentage is 40%</p> 
<p>Battery voltage / Load VA Battery voltage is 50.0V, output wattage is 2.00kVA</p> 	<p>Battery voltage / Load wattage Battery voltage is 50.0V, output wattage is 2.00kW</p> 
<p>Battery voltage / Discharging current Battery voltage is 54.0V, discharging current is 40A</p> 	<p>CPU software version CPU software version is 1100</p> 

6. Warning Code Table

When fault event happens, the fault LED is flashing. At the same time, warning code, icon  is shown on the LCD screen.

Warning Code	Warning Information	Audible Alarm	Trouble Shooting
07	Low battery		The battery voltage is too low, it should be charging.
09	Overload	Beep twice every second	Reduce the loads.
51	BMS doesn't allow inverter to discharge battery.		Inverter will stop discharging battery automatically.
52	BMS require inverter to charge battery.		Inverter will charge battery automatically.
60	BMS firmware version is not matched.		Upgrade the firmware of BMS.

7. Troubleshooting

This chapter describes the fault alarm and fault code for quick troubleshooting.

Table 7-1 Fault code

Fault Code	Fault Information	Trouble Shooting
01	PV voltage is too high	Reduce the number of PV modules in series.
02	Over current happen at PV port	Restart the unit, if the error happens again, please return to repair center.
04	Start circuit happen at PV port	Check if wiring is connect well.
07	Battery voltage is too high	Check if spec and quantity of batteries are meet requirements.
08	Over current happen at Battery	Restart the unit, if the error happens again, please return to repair center.
10	Abnormal LLC	Restart the unit, if the error happens again, please return to repair center.
11	Over current happen at Buckboost	Restart the unit, if the error happens again, please return to repair center.
13	Buckboost soft start failed	Restart the unit, if the error happens again, please return to repair center.
14	BuckBoost is out of balance	Restart the unit, if the error happens again, please return to repair center.
15	Buckboost current sensor failed	Restart the unit, if the error happens again, please return to repair center.
16	NO.2 Buckboost current sensor failed	Restart the unit, if the error happens again, please return to repair center.

17	Overfeed time out	Reduce the connected load by switching off some equipment.
18	The output overcurrent is abnormal	Restart the unit, if the error happens again, please return to repair center.
19	Output short circuited	Check if wiring is connected well and remove abnormal load.
21	OP current sensor failed	Output current sensor failed.
22	Output voltage is too low	Reduce the connected load.
23	Output voltage is too high	Restart the unit, if the error happens again, please return to repair center.
24	Over current or surge detected by Software	Restart the unit, if the error happens again, please return to repair center.
25	Hardware detect over current at inverter port	Restart the unit, if the error happens again, please return to repair center.
26	Invert soft start failed	Internal components failed. Restart the unit, if the error happens again, please return to repair center.
28	The DC component of the inverter current is abnormal	Restart the unit, if the error happens again, please return to repair center.
29	Inverter current sensor failed	Restart the unit, if the error happens again, please return to repair center.
30	Bus voltage is too low	Restart the unit, if the error happens again, please return to repair center.
31	Bus voltage is too high	AC Surge or internal components failed. Restart the unit, if the error happens again, please return to repair center.
33	Bus soft start failed	Internal components failed. Restart the unit, if the error happens again, please return to repair center.
34	Over temperature happen at heat sink	Check whether the ambient temperature is too high.
35	The inner temperature over	Check whether the ambient temperature is too high.
38	Leakage current fault	Restart the unit, if the error happens again, please return to repair center.
39	Leakage current sensor failed	Restart the unit, if the error happens again, please return to repair center.
40	Isolation resistance to ground of the PV string is too low	Restart the unit, if the error happens again, please return to repair center.
41	Grounding errors	1. Confirm correct grounding. 2. Restart the unit, if the error happens again, please return to repair center.

42	Relay check failure	Restart the unit, if the error happens again, please return to repair center.
43	CAN data loss	1. Check if communication cables are connected well and restart the inverter. 2. If the problem remains, please contact your installer.
44	Host data loss	
45	Synchronization data loss	
46	The firmware version of each inverter is not the same.	1. Update all inverter firmware to the same version. 2. Check the version of each inverter via LCD setting and make sure the CPU versions are same. If not, please contact your installer to provide the firmware to update. 3. After updating, if the problem still remains, please contact your installer.
47	The inverter Settings are inconsistent	1. Through the LCD control button on the inverter, the parameters of the machine are set to the same as those of other machines. 2. If the problem persists, contact the after-sales service.
48	Parallel installation is abnormal	Contact after-sales service for installation technical guidance
49	Parallel negative power protection	Restart the unit, if the error happens again, please return to repair center.
50	EEPROM failure	Restart the unit, if the error happens again, please return to repair center.
51	DSP1 communication failure	Restart the unit, if the error happens again, please return to repair center.
52	DSP2 communication failure	Restart the unit, if the error happens again, please return to repair center.

Appendix

Model	IVGM4648	IVGM5048
Battery Input Data		
Battery Voltage Range	40V~60V	
Max. charging and discharging current	100A/100A	
Max. charging and discharging power	4600W	5000W
Battery type	Li-Ion / Lead-acid	
DC Input Data (PV side)		
Max. recommended PV power	6000W	6500W
Max. PV voltage	550V	
Start voltage	130V	
PV voltage range	90V~550V	
MPPT voltage range	100V~500V	
MPPT Voltage Range for Full Load	200V~500V	200V~500V
Nominal voltage	360V	
Max. input current	15A/15A	
Max. shorted current	18A/18A	
Number of MPP trackers / strings per MPP tracker	2/1	
Grid Data		
Nominal Input Voltage	230Vac	
Input Voltage Range	184~264.5Vac*	
Nominal grid frequency	50/60Hz*	
Max. input current	40A	
Max. Charge Current	100A	
Max. AC output power	4600W	5000W
AC Output Rated Current	20A	21.7A
Max. output current	25A	25A
Max. Continuous AC Passthrough	30A	
Power factor	>0.99	
Displacement power factor	0.8leading..0.8lagging	
THDI	<3%	

AC Output Data (Back Up)		
Rated output power	4600VA/4600W	5000VA/5000W
Max. Output current	30A	
Rated AC output voltage	230Vac	
Rated AC output frequency	50/60Hz	
Efficiency		
Max. efficiency	97.6%	
Euro efficiency	97.0%	
MPPT efficiency	99.9%	
Protection		
Output over current protection	Integrated	
Output over power protection	Integrated	
Output shorted protection	Integrated	
Anti-islanding protection	Integrated	
GFCI Protection	Integrated	
Insulation Resistor Detection	Integrated	
General Data		
Operating temperature range	-25°C~60°C, >45°C Derating	
Protection degree	IP65	
Relative humidity	100%	
Cooling concept	Nature	
Altitude	2000m	
Communication	RS232/RS485	
BMS Communication	CAN/RS485	
Monitor module	WiFi/GPRS	
Display	LCD+LED	
Installation Style	Wall-mounted	
Warranty	10 years	
Grid Regulation	VDE-AR-N 4105; G99/1; EN50549-1; CEI 0-21; AS 4777.2; NRS 1072-1;	
Safety Regulation	IEC 62109-1/2; IEC 62040-1	
EMC	EN61000-6-1; EN61000-6-3	
Net Weight	34.8KG	
Gross Weight	40.0KG	
Product Dimension	520*493*229MM	
Package Dimension	632*585*315MM	

* According to local grid-connected standards

Features:

- Support WiFi for mobile monitoring
- 48V low voltage battery, transformer isolation topology
- Max. charging/discharging current of 100A
- AC couple to retrofit existing solar system
- Support storing energy from diesel generator
- Power supply can be switched automatically and switching time within 20ms